5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0404-001250	D7001,D8000	DIODE-SCHOTTKY
0406-001506	ZD1000,ZD1001,ZD1002	DIODE-TVS
0406-001506	ZD2001,ZD2002,ZD2004	DIODE-TVS
0406-001553	ZD7005,ZD7006	DIODE-TVS
0406-001592	ZD14013,ZD14014	DIODE-TVS
0406-001592	ZD14015,ZD14016	DIODE-TVS
0406-001592	ZD14017,ZD3000	DIODE-TVS
0406-001592	ZD3001,ZD3002,ZD3003	DIODE-TVS
0406-001592	ZD9000,ZD9001,ZD9002	DIODE-TVS
0406-001592	ZD9004,ZD9005,ZD9006	DIODE-TVS
0406-001592	ZD9007	DIODE-TVS
0406-001709	ZD13008,ZD13025	DIODE-TVS
0406-001715	ZD13026,ZD7001	DIODE-TVS
0406-001728	D7000	DIODE-TVS
0406-001729	ZD7003,ZD7004	DIODE-TVS
0406-001762	ZD13027,ZD13028	DIODE-TVS
0406-001762	ZD13029,ZD13030	DIODE-TVS
0406-001762	ZD3015,ZD3018,ZD3019	DIODE-TVS
0406-001762	ZD3020,ZD3021,ZD3022	DIODE-TVS
0406-001762	ZD3023	DIODE-TVS
0406-001763	D9001,ZD3010,ZD3011	DIODE-TVS
0406-001763	ZD3012,ZD3013,ZD3014	DIODE-TVS
0406-001763	ZD3016,ZD3017	DIODE-TVS
0406-001780	ZD13013,ZD13018	DIODE-TVS
0406-001780	ZD9009	DIODE-TVS
0406-001780	ZD9008	DIODE-TVS
0406-001787	V8000,V8001,ZD8000	DIODE-TVS
0406-001787	ZD8001	DIODE-TVS
0406-001805	ZD7000	DIODE-TVS
0406-001809	D13000,D13001	DIODE-TVS
0505-001883	Q8000	FET-SILICON
0601-003683	LED9000	LED
0801-003435	U14002	IC
1001-001755	U8005	IC
1001-001911	U2000	IC
1001-001975	U1002,U1015,U1016	IC
1001-001975	U2002	IC
1001-002022	U2005	IC

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1001-002038	U4007,U4008	IC
1001-002045	U7012	IC
1009-001066	U4009	IC
1107-002589	UME3002	IC
1201-003735	U4004	IC
1201-004029	U2003,U2004	IC
1201-004114	PAM1001	IC
1201-004134	U4000,U4001	IC
1201-004157	PAM1000	IC
1201-004166	PAM1002	IC
1201-004168	U8002,U8003	IC
1202-001120	U9003	IC
1203-008472	U9001	IC
1203-008719	U9006	IC
1203-008729	U3001	IC
1203-008797	U14007	IC
1203-008802	U8008	IC
1203-008811	U4006,U7005	IC
1203-008867	U4005	IC
1203-008882	U7016	IC
1203-009030	U7011	IC
1203-009031	U7006	IC
1203-009032	U9000	IC
1203-009035	U9004	IC
1204-003694	U1003	IC
1205-005729	U8004	IC
1205-005738	U6002	IC
1205-005871	U4013	IC
1205-005878	UCP500	IC
1205-005880	U4002	IC
1205-005907	U2001	IC
1209-002401	U4014	IC
1209-002428	U4012	IC
1209-002450	U4010	IC
1209-002540	U4011	IC
1404-001724	TH3000,TH5000,TH7000	THERMISTOR
1404-001724	TH7001,V4002	THERMISTOR
1405-001395	U14025,U14026,V2000	VARISTOR
1405-001395	V2006,V2011,V2012	VARISTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1405-001395	V2018,V2025,V4000	VARISTOR
1405-001395	V4001,V7000,V7004	VARISTOR
1405-001398	V7001	VARISTOR
1405-001404	U14027,V1200,V2001	VARISTOR
1405-001404	V2019,V2024,V2027	VARISTOR
1405-001404	V7002,V7005,V7007	VARISTOR
1405-001404	V7011,V7012	VARISTOR
1405-001415	C2081,C4087	VARISTOR
1405-001418	V7010	VARISTOR
1405-001424	V3001,V3002,V3003	VARISTOR
1405-001424	V3004,V3005	VARISTOR
1405-001445	V14001,V14002	VARISTOR
2007-007142	R4043,R8041,R8042	R-CHIP
2007-007310	R5008,R5026,R5055	R-CHIP
2007-007314	R4030,R4031	R-CHIP
2007-007741	R13015,R3000,R3001	R-CHIP
2007-007741	R3004,R3005,R3021	R-CHIP
2007-007741	R4000,R4001,R4007	R-CHIP
2007-007741	R4008,R4014,R4016	R-CHIP
2007-007741	R4019,R4022,R4023	R-CHIP
2007-007741	R7014,R7015,R8051	R-CHIP
2007-007741	R8052	R-CHIP
2007-007942	R5050	R-CHIP
2007-007946	R5052	R-CHIP
2007-008043	R3015	R-CHIP
2007-008211	R9005	R-CHIP
2007-008294	R8020	R-CHIP
2007-008296	R9000	R-CHIP
2007-008403	R7025	R-CHIP
2007-008420	R4015,R4018,U14011	R-CHIP
2007-008486	R9096	R-CHIP
2007-008531	R14001,R3011,R3013	R-CHIP
2007-008531	R3014,R5048,R7001	R-CHIP
2007-008531	R7003,R7004,R8022	R-CHIP
2007-008774	R3009,R3010	R-CHIP
2007-008785	R3025	R-CHIP
2007-009111	R3012	R-CHIP
2007-009157	R3016,R3027,R4042	R-CHIP
2007-009157	R5049,R5053,R5054	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2007-009157	R7007,R7021,R7022	R-CHIP
2007-009157	R7030,R8024,R8026	R-CHIP
2007-009157	R8029,R8043,R9002	R-CHIP
2007-009182	R4040	R-CHIP
2007-009201	R8011,R8015	R-CHIP
2007-009212	R13016,R3002,R5023	R-CHIP
2007-009212	R5024,R5034,R5035	R-CHIP
2007-009212	R5042,R5043,R5076	R-CHIP
2007-009212	R5090,R5091,R8012	R-CHIP
2007-009233	R7016,U14015	R-CHIP
2007-009314	R3024,R9094	R-CHIP
2007-009352	R6000,R9014	R-CHIP
2007-009361	R1000,R1003,R1004	R-CHIP
2007-009408	R4024,R8025,R9016	R-CHIP
2007-009766	R8027,R8028	R-CHIP
2007-009801	R3003,R3006,R3007	R-CHIP
2007-009801	R7018	R-CHIP
2007-009866	C13003,C13004,C13005	R-CHIP
2007-009866	R13017,R14002,R7002	R-CHIP
2007-009866	R7024,R9001,U14012	R-CHIP
2007-009924	R13006,R13007	R-CHIP
2007-009969	R8014	R-CHIP
2007-010202	R14005,R3017,R3018	R-CHIP
2007-010202	R3019,R3020,R7006	R-CHIP
2007-010202	R7012,R9095	R-CHIP
2007-010685	R7017,R7019	R-CHIP
2007-011043	R5009	R-CHIP
2007-011262	R4020,R5060,R5061	R-CHIP
2007-011262	R5063,R5064,R5065	R-CHIP
2007-011262	R5071,R5074,R5075	R-CHIP
2007-011262	R5080,R5081,R5082	R-CHIP
2007-011262	R5083,R8003	R-CHIP
2007-011378	R3008	R-CHIP
2007-011532	R8006	R-CHIP
2007-011542	R9007,R9013	R-CHIP
2007-011546	R5044,R5045,R5046	R-CHIP
2007-011546	R5047,R5056,R5057	R-CHIP
2007-011546	R5058,R5059	R-CHIP
2007-011591	R13018,R4002,R4003	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-011591	R4032,R4033,R5000	R-CHIP
2007-011591	R5001,R5002,R5003	R-CHIP
2007-011591	R5004,R5005,R5006	R-CHIP
2007-011591	R5007,R5010,R5011	R-CHIP
2007-011591	R5012,R5013,R5014	R-CHIP
2007-011591	R5015,R5017,R5018	R-CHIP
2007-011591	R5019,R5020,R5021	R-CHIP
2007-011591	R5022,R5028,R5029	R-CHIP
2007-011591	R5030,R5031,R5032	R-CHIP
2007-011591	R5033,R5036,R5037	R-CHIP
2007-011591	R7010,R7011	R-CHIP
2007-011594	R5092	R-CHIP
2007-011599	R8010	R-CHIP
2007-011648	R1007,R1008	R-CHIP
2007-012197	R7026	R-CHIP
2007-012202	R9006	R-CHIP
2203-000233	C4066,C4069,C7107	C-CERAMIC,CHIP
2203-000425	C4071	C-CERAMIC,CHIP
2203-000489	C7126	C-CERAMIC,CHIP
2203-000679	C14047,C14048	C-CERAMIC,CHIP
2203-000725	C14049	C-CERAMIC,CHIP
2203-001033	C7121	C-CERAMIC,CHIP
2203-002285	C14055	C-CERAMIC,CHIP
2203-005057	C4065	C-CERAMIC,CHIP
2203-005682	C1079,C1093,C14019	C-CERAMIC,CHIP
2203-005682	C14020,C14021,C14023	C-CERAMIC,CHIP
2203-005682	C14024,C3013,C3014	C-CERAMIC,CHIP
2203-005682	C3015,C3016,C3017	C-CERAMIC,CHIP
2203-005682	C3022,C3023,C3027	C-CERAMIC,CHIP
2203-005682	C3042,C3048,C3050	C-CERAMIC,CHIP
2203-005682	C4036,C4086,C8045	C-CERAMIC,CHIP
2203-005682	C8077,L1037	C-CERAMIC,CHIP
2203-005725	L1035	C-CERAMIC,CHIP
2203-005726	C8047,C8048	C-CERAMIC,CHIP
2203-005727	C5002	C-CERAMIC,CHIP
2203-005731	C2049,C8059,C8060	C-CERAMIC,CHIP
2203-005732	C13001,C8043,C8057	C-CERAMIC,CHIP
2203-005732	C8058	C-CERAMIC,CHIP
2203-005734	C9008	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C1000,C1002,C1017	C-CERAMIC,CHIP
2203-005736	C1019,C1043,C1047	C-CERAMIC,CHIP
2203-005736	C1055,C1059,C1091	C-CERAMIC,CHIP
2203-005736	C1096,C1097,C1098	C-CERAMIC,CHIP
2203-005736	C1099,C1100,C1106	C-CERAMIC,CHIP
2203-005736	C1112,C1113,C14035	C-CERAMIC,CHIP
2203-005736	C14036,C14037,C14038	C-CERAMIC,CHIP
2203-005736	C14041,C14058,C14059	C-CERAMIC,CHIP
2203-005736	C14060,C2003,C2013	C-CERAMIC,CHIP
2203-005736	C2014,C2015,C2017	C-CERAMIC,CHIP
2203-005736	C2046,C2050,C2051	C-CERAMIC,CHIP
2203-005736	C2054,C2055,C2058	C-CERAMIC,CHIP
2203-005736	C2062,C2067,C2083	C-CERAMIC,CHIP
2203-005736	C2084,C2085,C2089	C-CERAMIC,CHIP
2203-005736	C3031,C3032,C3033	C-CERAMIC,CHIP
2203-005736	C4020,C4021,C4029	C-CERAMIC,CHIP
2203-005736	C4030,C4035,C4067	C-CERAMIC,CHIP
2203-005736	C4079,C9092,C9097	C-CERAMIC,CHIP
2203-005736	C9098,L1004,L1018	C-CERAMIC,CHIP
2203-005736	L1019,L1021,L1036	C-CERAMIC,CHIP
2203-005736	L1041,L1044,L2012	C-CERAMIC,CHIP
2203-005736	L2019,L2043	C-CERAMIC,CHIP
2203-005777	C1076,C1107,C4031	C-CERAMIC,CHIP
2203-005779	C14005,C14013,C14022	C-CERAMIC,CHIP
2203-005789	C1020,C1022,C1028	C-CERAMIC,CHIP
2203-005789	C1048,C1049,C1052	C-CERAMIC,CHIP
2203-005789	C1057,C1075,C1102	C-CERAMIC,CHIP
2203-005789	L1005,L2008,L2009	C-CERAMIC,CHIP
2203-005789	L2024	C-CERAMIC,CHIP
2203-005806	C4050	C-CERAMIC,CHIP
2203-006048	C4091	C-CERAMIC,CHIP
2203-006121	C8044	C-CERAMIC,CHIP
2203-006194	C1077,C1101,C14032	C-CERAMIC,CHIP
2203-006194	C2045,C2048,C2056	C-CERAMIC,CHIP
2203-006194	C2059,C2064,C3044	C-CERAMIC,CHIP
2203-006194	C4009,C4011	C-CERAMIC,CHIP
2203-006260	C1018,C7150	C-CERAMIC,CHIP
2203-006305	L4019	C-CERAMIC,CHIP
2203-006318	C1029	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-006400	C1015,C14042,C2000	C-CERAMIC,CHIP
2203-006400	C2053,C3020,C3021	C-CERAMIC,CHIP
2203-006400	C3035,C3036,C3037	C-CERAMIC,CHIP
2203-006400	C4010,C4012,C4038	C-CERAMIC,CHIP
2203-006400	C4064,C4074,C4090	C-CERAMIC,CHIP
2203-006400	C5003,C5006,C7114	C-CERAMIC,CHIP
2203-006400	C7155,C8056	C-CERAMIC,CHIP
2203-006410	C1027	C-CERAMIC,CHIP
2203-006423	C3047,C3049,C4045	C-CERAMIC,CHIP
2203-006423	C4054,C4055,C4056	C-CERAMIC,CHIP
2203-006423	C4070,C4073,C6058	C-CERAMIC,CHIP
2203-006423	C7017,C7142,C8003	C-CERAMIC,CHIP
2203-006423	C8010,C9049	C-CERAMIC,CHIP
2203-006426	C1087,C1088	C-CERAMIC,CHIP
2203-006556	C1056,C7151,L1003	C-CERAMIC,CHIP
2203-006562	C1078,C2021	C-CERAMIC,CHIP
2203-006648	C3028	C-CERAMIC,CHIP
2203-006665	C2087	C-CERAMIC,CHIP
2203-006668	C3034,C5005	C-CERAMIC,CHIP
2203-006707	C2043,L2060	C-CERAMIC,CHIP
2203-006839	C14039,C4060,C7102	C-CERAMIC,CHIP
2203-006839	C7111,C7135	C-CERAMIC,CHIP
2203-006844	R13011,R13012,R13013	C-CERAMIC,CHIP
2203-006844	R13014	C-CERAMIC,CHIP
2203-006872	C8029,C8031	C-CERAMIC,CHIP
2203-006896	C2011,C2012,C2092	C-CERAMIC,CHIP
2203-006968	L1033	C-CERAMIC,CHIP
2203-006979	C2020,C2022,C2023	C-CERAMIC,CHIP
2203-006979	C2028,C2030,C3038	C-CERAMIC,CHIP
2203-007194	C2040	C-CERAMIC,CHIP
2203-007210	C3004	C-CERAMIC,CHIP
2203-007271	C7133,C7143,C8066	C-CERAMIC,CHIP
2203-007279	C1064	C-CERAMIC,CHIP
2203-007317	C3000,C3043,C6045	C-CERAMIC,CHIP
2203-007317	C6106,C6111,C8019	C-CERAMIC,CHIP
2203-007317	C8026,C8035,C8036	C-CERAMIC,CHIP
2203-007317	C8037,C8038,C8039	C-CERAMIC,CHIP
2203-007317	C8042,C9055,C9056	C-CERAMIC,CHIP
2203-007317	C9057,C9073	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-007391	C8033,C9033	C-CERAMIC,CHIP
2203-007393	C4057,C7021,C7044	C-CERAMIC,CHIP
2203-007393	C7067,C7071,C7072	C-CERAMIC,CHIP
2203-007393	C7073,C7137,C9029	C-CERAMIC,CHIP
2203-007393	C9030	C-CERAMIC,CHIP
2203-007425	C7097	C-CERAMIC,CHIP
2203-007486	C8070	C-CERAMIC,CHIP
2203-007544	C13023,C14056,C14057	C-CERAMIC,CHIP
2203-007544	C7123,C7127,C7128	C-CERAMIC,CHIP
2203-007544	C7130	C-CERAMIC,CHIP
2203-007621	C2001,C2007,C2010	C-CERAMIC,CHIP
2203-007621	C2038,C2071,C3005	C-CERAMIC,CHIP
2203-007621	C4028,C4032,C4033	C-CERAMIC,CHIP
2203-007621	C5000,C5001,C7019	C-CERAMIC,CHIP
2203-007621	C7026,C7030,C7105	C-CERAMIC,CHIP
2203-007621	C8020,C8046,C8061	C-CERAMIC,CHIP
2203-007621	C8062	C-CERAMIC,CHIP
2203-007781	C4037,C7147	C-CERAMIC,CHIP
2203-007796	C1003,C1041,C14040	C-CERAMIC,CHIP
2203-007796	C2025,C2026,C2027	C-CERAMIC,CHIP
2203-007796	C2032,C2033,C2035	C-CERAMIC,CHIP
2203-007796	C2037,C3001,C4002	C-CERAMIC,CHIP
2203-007796	C4003,C4023,C4041	C-CERAMIC,CHIP
2203-007796	C4042,C4046,C4052	C-CERAMIC,CHIP
2203-007796	C4053,C4058,C4083	C-CERAMIC,CHIP
2203-007796	C4088,C4089,C4093	C-CERAMIC,CHIP
2203-007796	C4095,C4096,C6000	C-CERAMIC,CHIP
2203-007796	C6005,C6006,C6007	C-CERAMIC,CHIP
2203-007796	C6012,C6013,C6014	C-CERAMIC,CHIP
2203-007796	C6015,C6017,C6018	C-CERAMIC,CHIP
2203-007796	C6022,C6028,C6029	C-CERAMIC,CHIP
2203-007796	C6030,C6031,C6032	C-CERAMIC,CHIP
2203-007796	C6033,C6034,C6035	C-CERAMIC,CHIP
2203-007796	C6036,C6037,C6041	C-CERAMIC,CHIP
2203-007796	C6042,C6043,C6049	C-CERAMIC,CHIP
2203-007796	C6050,C6051,C6052	C-CERAMIC,CHIP
2203-007796	C6053,C6054,C6055	C-CERAMIC,CHIP
2203-007796	C6056,C6057,C6059	C-CERAMIC,CHIP
2203-007796	C6060,C6061,C6062	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-007796	C6063,C6064,C6065	C-CERAMIC,CHIP
2203-007796	C6066,C6072,C6073	C-CERAMIC,CHIP
2203-007796	C6074,C6075,C6076	C-CERAMIC,CHIP
2203-007796	C6078,C6079,C6080	C-CERAMIC,CHIP
2203-007796	C6081,C6087,C6089	C-CERAMIC,CHIP
2203-007796	C6090,C6091,C6095	C-CERAMIC,CHIP
2203-007796	C6096,C6097,C6098	C-CERAMIC,CHIP
2203-007796	C6099,C6100,C6101	C-CERAMIC,CHIP
2203-007796	C6102,C6103,C6104	C-CERAMIC,CHIP
2203-007796	C6105,C6107,C6108	C-CERAMIC,CHIP
2203-007796	C6110,C6112,C6113	C-CERAMIC,CHIP
2203-007796	C6114,C6115,C6117	C-CERAMIC,CHIP
2203-007796	C6118,C6119,C6120	C-CERAMIC,CHIP
2203-007796	C6121,C6122,C6123	C-CERAMIC,CHIP
2203-007796	C6124,C6127,C6128	C-CERAMIC,CHIP
2203-007796	C6129,C6130,C6131	C-CERAMIC,CHIP
2203-007796	C6133,C6134,C6135	C-CERAMIC,CHIP
2203-007796	C6136,C6137,C6138	C-CERAMIC,CHIP
2203-007796	C6139,C6142,C6200	C-CERAMIC,CHIP
2203-007796	C7049,C7051,C7053	C-CERAMIC,CHIP
2203-007796	C7058,C7059,C7060	C-CERAMIC,CHIP
2203-007796	C7061,C7062,C7069	C-CERAMIC,CHIP
2203-007796	C7070,C7087,C7092	C-CERAMIC,CHIP
2203-007796	C7099,C7129,C7136	C-CERAMIC,CHIP
2203-007796	C7141,C7146,C7153	C-CERAMIC,CHIP
2203-007796	C8006,C8013,C8024	C-CERAMIC,CHIP
2203-007796	C8025,C8027,C8028	C-CERAMIC,CHIP
2203-007796	C8030,C8034,C8050	C-CERAMIC,CHIP
2203-007796	C8055,C9036,C9053	C-CERAMIC,CHIP
2203-007796	C9054,C9070,C9086	C-CERAMIC,CHIP
2203-007796	C9087,C9088,C9090	C-CERAMIC,CHIP
2203-008095	C6093,C6143,C6144	C-CERAMIC,CHIP
2203-008097	C1060,C1061,C1062	C-CERAMIC,CHIP
2203-008097	C1063,C1066,C1085	C-CERAMIC,CHIP
2203-008097	C7139,C8000,C8007	C-CERAMIC,CHIP
2203-008158	C7120,C7122,C7131	C-CERAMIC,CHIP
2203-008158	C7132	C-CERAMIC,CHIP
2203-008242	C14010,C14011,C14015	C-CERAMIC,CHIP
2203-008242	C14016,C14050,C14051	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-008242	C3006,C4051,C4082	C-CERAMIC,CHIP
2203-008242	C4084,C4085,C6010	C-CERAMIC,CHIP
2203-008242	C6027,C6044,C6046	C-CERAMIC,CHIP
2203-008242	C6109,C6126,C7011	C-CERAMIC,CHIP
2203-008242	C7012,C7014,C7015	C-CERAMIC,CHIP
2203-008242	C7016,C7040,C7043	C-CERAMIC,CHIP
2203-008242	C7045,C7046,C7047	C-CERAMIC,CHIP
2203-008242	C7048,C7050,C7052	C-CERAMIC,CHIP
2203-008242	C7065,C7066,C7068	C-CERAMIC,CHIP
2203-008242	C7085,C7089,C7090	C-CERAMIC,CHIP
2203-008242	C7091,C7093,C8018	C-CERAMIC,CHIP
2203-008242	C9002,C9017,C9018	C-CERAMIC,CHIP
2203-008242	C9019,C9043,C9044	C-CERAMIC,CHIP
2203-008242	C9062,C9064,C9077	C-CERAMIC,CHIP
2203-008242	C9078,C9080,C9094	C-CERAMIC,CHIP
2203-008242	C9095	C-CERAMIC,CHIP
2203-008394	L2026	C-CERAMIC,CHIP
2203-008400	C2031,C2034,C2036	C-CERAMIC,CHIP
2203-008403	C4094	C-CERAMIC,CHIP
2203-008470	C4049,C7086,C7158	C-CERAMIC,CHIP
2203-008528	C9006	C-CERAMIC,CHIP
2203-008529	C1001,C4022,C4025	C-CERAMIC,CHIP
2203-008529	C4026,C4027,C4039	C-CERAMIC,CHIP
2203-008529	C7148,C8073	C-CERAMIC,CHIP
2203-008572	C8074	C-CERAMIC,CHIP
2203-008689	C3024,C3026,C3030	C-CERAMIC,CHIP
2203-008689	C8067,C9015,C9026	C-CERAMIC,CHIP
2203-008692	C1074	C-CERAMIC,CHIP
2203-008749	C8069	C-CERAMIC,CHIP
2203-008795	C8068	C-CERAMIC,CHIP
2203-008844	C7002,C7004,C7018	C-CERAMIC,CHIP
2203-008844	C7020,C7022,C7025	C-CERAMIC,CHIP
2203-008844	C7027,C7029,C7031	C-CERAMIC,CHIP
2203-008844	C7033,C7034,C7036	C-CERAMIC,CHIP
2203-008844	C7038,C7041,C7055	C-CERAMIC,CHIP
2203-008844	C7056,C7057,C7075	C-CERAMIC,CHIP
2203-008844	C7081,C9003,C9004	C-CERAMIC,CHIP
2203-008844	C9005,C9007,C9034	C-CERAMIC,CHIP
2203-008844	C9079	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-008860	C14034,C7098,C7134	C-CERAMIC,CHIP
2203-008860	C8014,C8015,C9065	C-CERAMIC,CHIP
2203-008860	C9069,C9071,C9074	C-CERAMIC,CHIP
2203-008876	C1016,C14009,C14012	C-CERAMIC,CHIP
2203-008876	C14014,C14017,C14018	C-CERAMIC,CHIP
2203-008876	C3011,C7005,C7006	C-CERAMIC,CHIP
2203-008876	C7007,C7008,C7009	C-CERAMIC,CHIP
2203-008876	C7010,C7042,C7054	C-CERAMIC,CHIP
2203-008876	C7063,C7064,C7074	C-CERAMIC,CHIP
2203-008876	C7088,C7094,C7100	C-CERAMIC,CHIP
2203-008876	C7160,C8041,C9001	C-CERAMIC,CHIP
2203-008876	C9020,C9021,C9022	C-CERAMIC,CHIP
2203-008876	C9023,C9024,C9032	C-CERAMIC,CHIP
2203-008876	C9041,C9059,C9061	C-CERAMIC,CHIP
2203-008876	C9063,C9075,C9076	C-CERAMIC,CHIP
2203-008886	C13010,C13011,C13012	C-CERAMIC,CHIP
2203-008886	C13013	C-CERAMIC,CHIP
2203-008960	C14053,C14054,C7117	C-CERAMIC,CHIP
2203-009025	C1068,C1104,C2006	C-CERAMIC,CHIP
2203-009025	C2075,C2082	C-CERAMIC,CHIP
2203-009064	C6001,C6002,C6003	C-CERAMIC,CHIP
2203-009064	C6008,C6009,C6020	C-CERAMIC,CHIP
2203-009167	C4076,C4077	C-CERAMIC,CHIP
2203-009444	C1086,C7096	C-CERAMIC,CHIP
2203-009537	C3008,C3009,C6004	C-CERAMIC,CHIP
2203-009537	C6040,C6047,C6116	C-CERAMIC,CHIP
2203-009537	C7077,C7078,C7079	C-CERAMIC,CHIP
2203-009537	C7082,C7083,C7084	C-CERAMIC,CHIP
2203-009537	C7156,C7157,C9000	C-CERAMIC,CHIP
2203-009537	C9014,C9040,C9045	C-CERAMIC,CHIP
2203-009537	C9046,C9047,C9096	C-CERAMIC,CHIP
2203-009551	C2004,C9093	C-CERAMIC,CHIP
2203-009618	C1067,C8002,C9009	C-CERAMIC,CHIP
2203-009618	C9010,C9011,C9012	C-CERAMIC,CHIP
2203-009618	C9013,C9031,C9038	C-CERAMIC,CHIP
2203-009618	C9039	C-CERAMIC,CHIP
2203-009732	C7003,C7023,C7024	C-CERAMIC,CHIP
2203-009732	C7035,C7037,C7039	C-CERAMIC,CHIP
2203-009732	C7076,C7080	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-009733	C14000,C14001,C14002	C-CERAMIC,CHIP
2203-009733	C14003,C14004,C14006	C-CERAMIC,CHIP
2203-009733	C14025,C14033,C2019	C-CERAMIC,CHIP
2203-009733	C2024,C2029,C2044	C-CERAMIC,CHIP
2203-009733	C2047,C3012,C4059	C-CERAMIC,CHIP
2203-009733	C9027,C9028,C9035	C-CERAMIC,CHIP
2203-009733	C9051,C9052	C-CERAMIC,CHIP
2203-009735	C6019,C6021,C6038	C-CERAMIC,CHIP
2203-009735	C6039,C6067,C6068	C-CERAMIC,CHIP
2203-009735	C6082,C6084	C-CERAMIC,CHIP
2203-009736	C4092,C6125,C8023	C-CERAMIC,CHIP
2203-009736	C9025,C9042	C-CERAMIC,CHIP
2203-009812	C7109	C-CERAMIC,CHIP
2203-009848	C8040,C8078,C8079	C-CERAMIC,CHIP
2203-009858	C14052,C3002,C3010	C-CERAMIC,CHIP
2203-009858	C4048,C7000,C7001	C-CERAMIC,CHIP
2203-009858	C7118,C7119,C7138	C-CERAMIC,CHIP
2203-009859	C8004,C9081	C-CERAMIC,CHIP
2203-009917	C8009,C8011	C-CERAMIC,CHIP
2203-009969	C7108	C-CERAMIC,CHIP
2409-001365	C4047	CAPACITOR
2409-001387	TA7004,TA7005	CAPACITOR
2409-001399	TA7000,TA7001,TA7002	CAPACITOR
2409-001399	TA7003	CAPACITOR
2703-002204	L2017	INDUCTOR
2703-002907	L4021	INDUCTOR
2703-002955	C1013	INDUCTOR
2703-002958	L1029,L1053,L2020	INDUCTOR
2703-002958	L2030	INDUCTOR
2703-002959	L14000,L14002	INDUCTOR
2703-002999	L4025	INDUCTOR
2703-004000	C1032,C4017,C4018	INDUCTOR
2703-004012	C1050,C1054,C1071	INDUCTOR
2703-004012	C1081,C1083,C1090	INDUCTOR
2703-004012	C4034,L1049,L2045	INDUCTOR
2703-004013	C2041,C2080,L1002	INDUCTOR
2703-004013	L1051,L2002,L2003	INDUCTOR
2703-004013	L2040	INDUCTOR
2703-004014	C1042,C1080,C4015	INDUCTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2703-004014	C4016,L4017	INDUCTOR
2703-004018	L1020	INDUCTOR
2703-004032	C1058,C1082,C2042	INDUCTOR
2703-004032	L4034	INDUCTOR
2703-004034	C2077,C4019,L1022	INDUCTOR
2703-004034	L1027,L2047,L4003	INDUCTOR
2703-004034	L4006,L4045,L4046	INDUCTOR
2703-004035	C1053,C1065,C1070	INDUCTOR
2703-004035	C1073,L1016,L1039	INDUCTOR
2703-004035	L1050,L2027,L2084	INDUCTOR
2703-004036	C1007,L2005	INDUCTOR
2703-004037	C1072,C1084,C2063	INDUCTOR
2703-004037	L1031,L1038,L1055	INDUCTOR
2703-004037	L2041,L2056	INDUCTOR
2703-004038	L1040,L4018	INDUCTOR
2703-004090	L2021	INDUCTOR
2703-004193	C1109	INDUCTOR
2703-004286	C2057	INDUCTOR
2703-004300	C2018,L1032,L2001	INDUCTOR
2703-004300	L2018,L2039,L2048	INDUCTOR
2703-004317	L4004,L4005	INDUCTOR
2703-004328	L4022,L4023	INDUCTOR
2703-004366	L2029,L4020,L4032	INDUCTOR
2703-004367	C1024,L1014,L2006	INDUCTOR
2703-004367	L2015	INDUCTOR
2703-004408	L2023	INDUCTOR
2703-004703	L1052	INDUCTOR
2703-004764	L4029	INDUCTOR
2703-004853	L1048,L1056	INDUCTOR
2703-005058	L3001	INDUCTOR
2703-005067	L4033,L7021,L9008	INDUCTOR
2703-005067	L9009,L9010,L9011	INDUCTOR
2703-005088	C1069,L2025,L2032	INDUCTOR
2703-005088	L2080	INDUCTOR
2703-005200	L4026	INDUCTOR
2703-005201	L7004,L7005,L7018	INDUCTOR
2703-005224	L9001	INDUCTOR
2703-005225	L3000,L8011,L9004	INDUCTOR
2703-005226	L7001,L7002,L7006	INDUCTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-005226	L7023	INDUCTOR
2703-005233	L7019,L7020,L8000	INDUCTOR
2703-005233	L8003,L8006,L8007	INDUCTOR
2703-005418	L9007	INDUCTOR
2703-005430	L1042,L1043	INDUCTOR
2703-005505	L8001,L8002	INDUCTOR
2703-005509	L7007,L7010,L7012	INDUCTOR
2703-005509	L7022,U14017	INDUCTOR
2703-005555	L4043,L4044	INDUCTOR
2703-005660	L7000,L7013,L7014	INDUCTOR
2703-005660	L7024	INDUCTOR
2703-005661	L7003,L7008,L7009	INDUCTOR
2703-005661	L7011	INDUCTOR
2703-005663	L9002,L9005	INDUCTOR
2801-005393	OSC7000	CRYSTAL-UNIT
2805-001118	OSC4000,TCX3000	OSCILLATOR
2901-001690	C6011,C6023,C6024	FILTER-EMI SMD
2901-001690	C6025,C6026,C6048	FILTER-EMI SMD
2901-001690	C6069,C6070,C6085	FILTER-EMI SMD
2901-001690	C6140,C6141	FILTER-EMI SMD
2903-001576	F4000,F4001	FILTER-CERAMIC
2904-002190	F1001	FILTER-SAW
2904-002260	F1002	FILTER-SAW
2904-002286	F4002	FILTER-SAW
2904-002296	F1003	FILTER-SAW
2904-002323	F4003	FILTER-SAW
2904-002349	F2006	FILTER-SAW
2904-002355	F4004	FILTER-SAW
2904-002362	F1004,F2003	FILTER-SAW
2904-002378	F2002	FILTER-SAW
2911-000432	F2005	FILTER
2911-000453	F2001	FILTER
2911-000455	F2007	FILTER
3003-001244	MIC8000	MIC-CONDENSOR
3301-001885	L8004	CORE-FERRITE BEAD
3301-002223	L14001,L14003,L2042	CORE-FERRITE BEAD
3301-002223	U14000,U14001	CORE-FERRITE BEAD
3301-002228	L8005	CORE-FERRITE BEAD
3301-002235	L4038,L4039	CORE-FERRITE BEAD

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3301-002237	L1000,L1006,L1026	CORE-FERRITE BEAD
3301-002237	L1030,L1034,L2000	CORE-FERRITE BEAD
3301-002237	L2011,L2013,L2014	CORE-FERRITE BEAD
3301-002237	L2035,L2050,L2057	CORE-FERRITE BEAD
3301-002237	L4000,L4001,L4002	CORE-FERRITE BEAD
3301-002237	L4030,L4031	CORE-FERRITE BEAD
3301-002238	L2064,L2065,L2066	CORE-FERRITE BEAD
3301-002238	L3005	CORE-FERRITE BEAD
3301-002242	L2049	CORE-FERRITE BEAD
3301-002243	L1009	CORE-FERRITE BEAD
3301-002245	L1001	CORE-FERRITE BEAD
3301-002248	L14004,L14005,L14006	CORE-FERRITE BEAD
3301-002279	L3003,U14004	CORE-FERRITE BEAD
3301-002312	L2033,L2034,L2036	CORE-FERRITE BEAD
3301-002312	L2037,L2038,L3002	CORE-FERRITE BEAD
3301-002312	L3004,L3008,L9000	CORE-FERRITE BEAD
3301-002312	L9003,L9006,R4006	CORE-FERRITE BEAD
3301-002331	L7016,L7017,L8010	CORE-FERRITE BEAD
3301-002375	L8008,L8009	CORE-FERRITE BEAD
3705-001937	RFS1000,RFS10003	CONNECTOR-COAXIAL
3705-001937	RFS1001	CONNECTOR-COAXIAL
3709-001892	CN3000	CONNECTOR-CARD EDGE
3711-008508	HDC14000	CONNECTOR-HEADER
3711-008741	HEA14000	CONNECTOR-HEADER
3711-008847	HDC7000	CONNECTOR-HEADER
3711-008997	HDC9001	CONNECTOR-HEADER
3711-009058	HEA3000	CONNECTOR-HEADER
3711-009302	HEA14001	CONNECTOR-HEADER
3711-009312	CON10001	CONNECTOR-HEADER
3711-009321	HDC9000	CONNECTOR-HEADER
3712-001604	ANT2007,ANT2014	CONNECTOR
3712-001604	ANT2016,ANT2020	CONNECTOR
3712-001604	ANT7000,ANT7001	CONNECTOR
3712-001604	ANT7002,ANT7003	CONNECTOR
3712-001604	ANT7004,ANT7005	CONNECTOR
3712-001604	ANT7006	CONNECTOR
3712-001621	ANT8002,ANT8003	CONNECTOR
3712-001626	ANT2011,ANT2015	CONNECTOR
3712-001626	ANT2021,ANT4000	CONNECTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3712-001626	ANT8000,ANT8001	CONNECTOR
3712-001634	ANT3000,ANT3001	CONNECTOR
3712-001634	ANT3002,ANT3003	CONNECTOR
3712-001634	ANT3004,ANT3005	CONNECTOR
3712-001634	ANT7007,ANT7008	CONNECTOR
3712-001666	ANT2000,ANT2005	CONNECTOR
3712-001666	ANT4002	CONNECTOR
3712-001694	ANT1001,ANT2001	CONNECTOR
3712-001694	ANT2006,ANT2008	CONNECTOR
3712-001694	ANT2018,ANT4001	CONNECTOR
3712-001731	ANT2004	CONNECTOR
4709-002196	F1000	RF-MODULE
4709-002416	F2000	RF-MODULE
4709-002623	U4003	RF-MODULE

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.

Confidential and proprietary-the contents in this service guide subject to change without prior notice
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.